

# PUR35 CHEMICAL

Compact, mobile, multi-use fume extraction unit

**PUREX**  
CLEAN AIR FOR EVERYONE



## Description & features

- High performance cost effective machine
- Highest grade carbon technology
- Simple to install and easy to relocate
- Adjustable airflow

## Filters



Main Filter Code

113862

Description

Chemical

## Specification

Volume Part Number	90v - 254v
Volume Part Number	0AL4180
Wattage	1.1kW
Frequency	50Hz / 60Hz
Cabinet Height	630mm
Cabinet Width	370mm
Cabinet Depth	520mm
Cabinet Weight	45kg
Airflow	400m3/h
Sound Level	<60dBa

## Machine supplied with

- 1 x Main Filter • 1 x Connection Kit • 1 x Power Cable • 1 x Manual

Find out more: [W purex.co.uk](http://W purex.co.uk) | [T +44 \(0\)1405 746030](tel:+44(0)1405746030) | [E purex@purex.co.uk](mailto:purex@purex.co.uk)

Registered Office: Purex International Limited, QWP House, Island Drive, Capitol Park, Thorne, Doncaster DN8 5UE  
Registered No. 5136616 England | VAT No. GB842 5025 49 | WEEE Producer Registration Number: WEE/CE0067TX  
\*Goods are subject to change | \*Illustrations are 3D created visual representations

# PUR35 CHEMICAL

# Options

Compact, mobile, multi-use fume extraction unit

## Connection kit

**100105**

Hose End Diameter	Hose Length	Purex Inlet Diameter
100mm	3m	100mm

Connect to 100mm diameter pipe/port

2.0m

**100107**

Hose End Diameter	Hose Length	Purex Inlet Diameter
100mm	2m	100mm

Connect to 100mm diameter pipe/port

3.0m

**100191**

Hose End Diameter	Hose Length	Purex Inlet Diameter
50mm	1.5m	100mm

Connect to 50mm diameter pipe/port or Purex valve

1.5m 0.5m

**100193**

Hose End Diameter	Hose Length	Purex Inlet Diameter
50mm	3m	100mm

Connect to 50mm diameter pipe/port or Purex valve

3m

**120270**

Hose End Diameter	Hose Length	Purex Inlet Diameter
100mm	1.5m	100mm

Connect to 100mm diameter pipe/port

1.5m

**120292**

Hose End Diameter	Hose Length	Purex Inlet Diameter
80mm	1.3m	100mm

Connect to 80mm diameter pipe/port

1.3m

PUR35

## Interfacing

Interfacing can remotely start the Purex machine when the connected machine starts.

Interfacing can also warn the connected machine when the Purex machine is in alarm.

Your Machine

10011010



10011010

Extractor

Take a look through our [Interfacing Guide](#) to see our extensive range of options